

### TIRE CHANGERS



#### Performance Tire Changer

Tilt Back Tower  
30" External Clamping  
Integrated Wheel Lift  
Three Helper Arms

Electric or Air Motor  
16" Bead Breaker  
16" Rim Width  
44" Tire Diameter

**APX90**



#### Performance Tire Changer

Tilt Back Tower  
30" External Clamping  
Optional Wheel Lift  
Two Helper Arms

Electric or Air Motor  
16" Bead Breaker  
16" Rim Width  
44" Tire Diameter

**APX80**



#### Rim Clamp Tire Changer

Swing Arm Tower  
22" External Clamping  
Upgradeable to 28" External  
One Helper Arm

Electric or Air Motor  
17" Bead Breaker  
14" Rim Width  
50" Tire Diameter

**7065X**



#### Rim Clamp Tire Changer

Swing Arm Tower  
22" External Clamping  
Upgradeable to 28" External

Electric or Air Motor  
17" Bead Breaker  
14" Rim Width  
50" Tire Diameter

**5065X**



#### Rim Clamp Tire Changer

Swing Arm Tower  
21" External Clamping

Electric or Air Motor  
12" Bead Breaker  
14" Rim Width  
50" Tire Diameter

**5040X**



#### Center Post Tire Changer

10" to 17-1/2" Wheel Size

Air Power  
7-1/2 gallon Surge Tank  
10-1/2" Rim Width  
38" Tire Diameter

**4050A**

### 50XX-70XX-APX TIRE CHANGER ACCESSORIES

Outside Clamp Set	13" - 24"	<b>184327</b>	Duckheads	Nylon	<b>183061</b>
	16" - 28"	<b>184958</b>		Steel	<b>182788</b>
Clamp Socks	10 pack	<b>183604</b>	Inserts for 182788	12 pack	<b>182963</b>
Lift Tool Socks	10 pack	<b>183605</b>	Bead Loosener Socks	2 pack	<b>183606</b>

### 4050A TIRE CHANGER ACCESSORIES

Hold Down Cone	<b>108276</b>	Combo Tool	<b>768</b>
----------------	---------------	------------	------------