

Tired Of Removing The Bearings

Machine Late Model Ford F-150 2 Wheel Drive Rotors
With Out Removing The Bearings

2004 and Later Models

designed specifically for the F150 2wd



- Time Saving Set Up
- Less Time Mounting The Rotor
- Kit Includes: 1) outboard drive locator
1) inboard centering bushing

AS 5532

Mounting Instructions

1. Clean Hub Assembly
2. Slide Back Support Bushing On Arbor
3. Slide Rotor Onto Support Bushing And Slide Drive On Arbor Into Rotor With Slot Over Stud
4. Install Spacers As Needed (Self Aligning Suggested) And Arbor Nut
5. Use Silencer Band
6. Machine Rotor

Note: Always remove Any ABS Sensor

Distributed By: **SAVEquipment LLC**

Price: \$149.00 + Tax (freight included)

Call Gary: 901.484.1519

Fax: 800.484.1519